Wiring connection for BRP models only



Open the blue square connector that connects the black/white to white
Connect the black/white to the brown with the blue square connector.